



Coastal Engineering

Technical Note

PROTECTING TIMBER PILES IN SEAWATER ENVIRONMENTS

PURPOSE: Timber piles are widely used in coastal construction. This note discusses marine organisms that attack timber piles, methods of preservation, and repair options.

BACKGROUND: In coastal construction timber piles are used as structural members for piers, wharves, trestles, jetties, groins, and bulkheads. A twelve-inch diameter untreated timber pile can be completely destroyed in as little as six months by marine borers if located in seawater. Fortunately, effective preservatives that prevent this type of damage are available. Life expectancies of 20 years or more are reasonable for properly treated piles.

MARINE ORGANISMS:

1. Teredo, or ship worms, are long worm-like organisms that attack piles from waterline to midline. The piles interior can be completely destroyed without showing any external damage. *Teredo* can be found throughout the United States in any brackish water with a salinity over 5 parts per thousand. If the possibility exists for saltwater intrusion at a given site, it is best to use a marine creosote dosage for any pile driven there (see Table 1).
2. *Limnoria tripunctata* (gribbles) are crustacean borers that attack timber piles in the tidal zone. Waves then remove the weakened wood producing a characteristic hourglass shape. Until recently, *Limnoria* was thought to only inhabit warm and moderate waters, up to New York City on the east coast, and Point Conception, California on the west coast. The latest research indicates that the cleanliness of the water is an important factor. As water pollution is reduced, *Limnoria* has been reported as far north as southern New England and Oregon, but the amount of infestation is light north of Norfolk, Virginia on the east coast, and north of Point Conception on the west coast.

3. Pholads are tropical crustaceans found in the Panama Canal and in the tropical Pacific. They have not been found in significant numbers in the continental United States, although they are thought to be present in south Florida. North of Jacksonville their presence is presently disregarded. Pholads are not affected by waterborne salts. Since pholads are usually present in combination with *Teredo* and *Limnoria*, dual treatments are necessary.

PRESERVATIVES FOR FRESH WATER

USES:

In fresh water, piles can be effectively treated with reduced amounts of creosote or waterborne salts (Table 1).

In addition, pentachlorophenol, a powerful preservative, may also be used to increase pile

life. Pentachlorophenol should not be used in salt or brackish water because it hydrolyzes and breaks down.

PRESERVATIVE TREATMENTS: All of the treatments discussed reduce the strength of the pile. Table 2 lists the reduced values which should be taken into account when designing a structure. Creosote or creosote/coal-tar mixtures are very effective against *Teredo*; 20 pounds per cubic foot retentions are usually specified in the marine environment. Where *Limnoria* attack is light and *Teredo* attack is heavy, piles can be protected with the heavier creosote treatments listed in Table 1. Heavier attacks of *Limnoria* are not deterred by creosote, but they can be effectively controlled by waterborne salts.

Table 1. Pile Preservative Treatments
(in pounds per cubic foot)^a

Condition and Material	Oilborne Preservatives				Waterborne Salts	
	Creosote	Creosote w/Coal Tar	Creosote w/Petroleum	Pentachlorophenol	Ammoniacal Copper Arsenate (ACA)	Chromated Copper Arsenate (CCA)
COASTAL WATERS						
<i>Teredo</i> Present, No <i>Limnoria</i> (Coastal Douglas Fir)	20.0	--	--	--	--	--
(Southern Pine)	20.0	20.0	--	--	--	--
<i>Teredo</i> Present, <i>Limnoria</i> Light (Coastal Douglas Fir)	22.0	--	--	--	--	--
(Southern Pine)	25.0	25.0	--	--	--	--
<i>Limnoria</i> Heavy, No Pholads (Coastal Douglas Fir)	--	--	--	--	2.50	2.50
(Southern Pine)	--	--	--	--	2.50	2.50
FRESH WATER or ONSHORE						
(Coastal Douglas Fir, Western Hemlock, and Lodgepole Pine)	17.0	17.0	17.0	0.85	1.00	1.00
(Southern, Ponderosa, Jack, and Red Pine)	12.0	12.0	12.0	0.60	0.80	0.80
DUAL TREATMENTS						
Where <i>Teredo</i> , <i>Limnoria</i> , and Pholads are active, or in southern areas where the borer hazard is uncertain (Coastal Douglas Fir, Southern Pine)	--	--	--	--	1.00	1.00
First Treatment	--	--	--	--	--	--
Second Treatment	20.0	--	--	--	--	--

^a For detailed information on specifications, see current standards from the American Wood Preservers Association (AWPA) and the American Wood Preservers Bureau (AWPB).

(From NAVFACINST 6250.4B, 1982)

Ammonical copper arsenate (ACA) is generally applied to Douglas Fir, and chromated copper arsenate (CCA) is generally applied to southern pine. Retentions of 2.5 pounds per cubic foot are sufficient to repel *Limnoria* and Teredo, however, the waterborne salts significantly reduce the strength of the piles.

To overcome the strength reductions of large waterborne salt applications, dual treatments are recommended to protect against heavy infestations of Teredo

and *Limnoria*, as well as pholads. First a waterborne salt is applied at 1 pound per cubic foot retention and allowed to dry. Air drying is thought to reduce strength less than kiln drying (CEL, 1979). This is followed by 20 pounds per cubic foot retention of creosote.

Whether 2.5 pounds per cubic foot of waterborne salts or dual treatment of piles is used for heavy *Limnoria* and Teredo infestation is a matter of economics and strength requirements. Dual treatment is usually the most expensive method. Single treatment with either 2.5 pounds per cubic foot of waterborne salts or 25.0 pounds per cubic foot of creosote is less expensive than dual treatment with 1.0 pound per cubic foot of salts and 20.0 pounds per cubic foot of creosote. In order to determine what is recommended at a particular location it is advisable to consult the American Wood Preservers Institute, local and state agencies and/or local harbor authorities.

If the flexural strength of the piles is important, as in fender systems, creosote treated piles should be used as they are the strongest of the treated piles.

Table 2. Average Mechanical Properties

Flexural Properties					
Type of Treatment	No. of Test Piles	Modulus of Rupture (psi)	Modulus of Elasticity in Flexure (10 ⁶ psi)	Average Absorb Energy in Flexure (in.-lb/cu in.)	Compressive Strength, F _c (psi)
Fir					
Untreated	5	8,394	1.922	6.338	3,346
Creosote ^b	5	6,862	1.584	4.202	a
ACA dual ^b	10	6,111	1.537	3.059	2,714
CCA dual ^b	10	3,844	1.171	3.364	2,333
ACA	5	5,620	1.416	2.078	2,462
Pine					
Untreated	5	8,007	1.942	5.240	a
Creosote ^b	5	5,950	a	a	a
ACA dual ^b	10	4,725	1.568	2.829	a
CCA dual ^b	10	4,167	1.441	2.413	a
ACA	5	5,534	1.538	a	a
CCA	5	5,410	a	a	a

^aNo value is provided because of the large spread in measured values for a small number of samples.

^bIncludes both air-dried and kiln-dried specimens (5 each).

(From CEL, 1979)

REPAIR OF DAMAGED PILES: For piles already damaged by marine organisms, there are a number of options for repair. The damaged piling can be removed and replaced. If the damage is not too severe, a plastic jacket can be placed around the pile, smothering the present organisms and preventing new organisms from entering. Heavily damaged piles can be reinforced with concrete. This can be done by placing a nylon jacket around the pile (adding reinforcement as required) and filling the jacket with tremie concrete. A similar method is to enclose the damaged portion of the pile with a fiberglass form, installing the required reinforcement and filling the space between the form and the pile with hydrophilic epoxy (U.S. Army, in publication). These last two methods allow the continued use of the structure while the piles are being repaired. Also, external reinforcement with heavy steel pipe is possible, although the steel would require corrosion protection.

ADDITIONAL INFORMATION: Contact AWPI, 1651 Old Meadow Road, McLean, VA, 22102 or call (800) 336-0148.

REFERENCES:

- AMERICAN WOOD PRESERVERS' ASSOCIATION, "Book of Standards," AWPB, Bethesda, MD, June 1981.
- CIVIL ENGINEERING LABORATORY, "Treated Wood for Marine Use," Techdata Sheet 78-50, Naval Construction Battalion Center, Port Hueneme, CA, 4 p., 1978.
- CIVIL ENGINEERING LABORATORY, "Mechanical Properties of Preservative Treated Marine Piles," Techdata Sheet 79-07, Naval Construction Battalion Center, Port Hueneme, CA, 4 p., 1979.
- JACHOWSKI, R. A., "Factors Affecting the Economic Life of Timber in Coastal Structures," Technical Memorandum No. 66, Beach Erosion Board, Washington, D. C., 13 p., 1955.
- NAVAL FACILITIES ENGINEERING COMMAND, "NAVFACINST 6250.4B, Selection, Procurement and Use of Preservative-Treated Wood Products," Department of the Navy, Alexandria, VA, 8 p., 1982.
- U.S. ARMY, CORPS OF ENGINEERS, "Construction Materials for Coastal Structures," Washington, D. C., in publication.
- AMERICAN WOOD PRESERVERS BUREAU, "Book of Standards," AWPB, Arlington, VA, 1982.